

Ø 3.5 mm			Ø 3.75 mm			Ø 4.0 mm			Ø 4.5 mm			Ø 5.0 mm			Ø 5.5 mm			Ø 6.5 mm					
RB (Regular Base)			RB (Regular Base)			RB (Regular Base)			RB (Regular Base)			WB (Wide Base)			WB (Wide Base)			WB (Wide Base)					
Roxolid® SLActive®			Roxolid® SLA®			Roxolid® SLActive®			Roxolid® SLA®			Roxolid® SLActive®			Roxolid® SLA®			Roxolid® SLActive®			Roxolid® SLA®		
6 mm	–	–	6 mm	061.4306	061.4506	6 mm	061.5306	061.5506	6 mm	061.6306	061.6506	6 mm	061.7306	061.7506	6 mm	061.8306	061.8506	6 mm	061.9306	061.9506			
8 mm	061.3308	061.3508	8 mm	061.4308	061.4508	8 mm	061.5308	061.5508	8 mm	061.6308	061.6508	8 mm	061.7308	061.7508	8 mm	061.8308	061.8508	8 mm	061.9308	061.9508			
10 mm	061.3310	061.3510	10 mm	061.4310	061.4510	10 mm	061.5310	061.5510	10 mm	061.6310	061.6510	10 mm	061.7310	061.7510	10 mm	061.8310	061.8510	10 mm	061.9310	061.9510			
12 mm	061.3312	061.3512	12 mm	061.4312	061.4512	12 mm	061.5312	061.5512	12 mm	061.6312	061.6512	12 mm	061.7312	061.7512	12 mm	061.8312	061.8512	12 mm	061.9312	061.9512			
14 mm	061.3314	061.3514	14 mm	061.4314	061.4514	14 mm	061.5314	061.5514	14 mm	061.6314	061.6514	14 mm	061.7314	061.7514	14 mm	061.8314	061.8514	14 mm	061.9314	061.9514			
16 mm	061.3316	061.3516	16 mm	061.4316	061.4516	16 mm	061.5316	061.5516	16 mm	061.6316	061.6516	16 mm	061.7316	061.7516	16 mm	061.8316	061.8516	16 mm	061.9316	061.9516			
18 mm	061.3318	061.3518	18 mm	061.4318	061.4518	18 mm	061.5318	061.5518	18 mm	061.6318	061.6518	18 mm	061.7318	061.7518	18 mm	–	–	18 mm	–	–			




Drill No.	Depth Gauge	Alignment Pin
1 (Pilot Drill)	Ø 2.2 mm	Ø 2.2 mm
2	Ø 2.8 mm	Ø 2.8 mm
3	Ø 3.2 mm	Ø 3.2 mm
4	Ø 3.5 mm	Ø 3.5 mm
5	Ø 3.7 mm	Ø 3.7 mm
6	Ø 4.2 mm	Ø 4.2 mm
7	Ø 4.7 mm	Ø 4.7 mm
8	Ø 5.2 mm	Ø 5.2 mm
9	Ø 6.2 mm	Ø 6.2 mm



Healing Abutment for Crown, AH 2 mm	Healing Abutment for Crown, AH 4 mm	Healing Abutment for Bridge, AH 2 mm	Healing Abutment for Bridge, AH 4 mm	Healing Abutments for Crown, AH 2 mm	Healing Abutments for Crown, AH 4 mm	Healing Abutments for Crown – Wide Profile, AH 2 mm	Healing Abutments for Crown – Wide Profile, AH 4 mm	Healing Abutment for Bridge, AH 2 mm	Healing Abutment for Bridge, AH 4 mm
Table with diameters 4.0, 5.0, 6.5, 7.5 mm	Table with diameters 4.0, 5.0, 6.5, 7.5 mm	Table with diameter 5.0 mm	Table with diameter 5.0 mm	Table with diameters 4.0, 5.0, 6.5, 7.5 mm	Table with diameters 4.0, 5.0, 6.5, 7.5 mm	Table with diameters 6.0, 7.5 mm	Table with diameters 6.0, 7.5 mm	Table with diameter 5.0 mm	Table with diameter 5.0 mm


Torque Control Device		066.1100	BL Bone Profiler Kit	
Ratchet		046.119	BL Bone Profiler 1	026.0022
Holding Key		046.064	BL Bone Profiler 2	026.0023
Implant depth gauge		066.2000	BL Bone Profiler 3	026.0024
			Guiding Pin for BLX Implants	066.00255
			Abutment removal kit	
			RB/WB Abutment-Removal Screw	065.0007
			Removal Tool	065.0008 / 065.0009
			Selection guide for the Straumann® Modular Cassette and instruments	



BLX Healing Abutment selection Quick Guide

The BLX Healing Abutment selection determines the available options for the final restoration. Therefore, always communicate the implant diameter and the selected healing abutment to the restoring dentist or dental lab in order to facilitate the appropriate final abutment selection.

Straumann® BLX Implant System – Healing Abutment selection Quick Guide (T04658/en).



International Headquarters
Institut Straumann AG
Peter Merian-Weg 12
CH-4002 Basel, Switzerland
Phone +41 (0)61 965 11 11
Fax +41 (0)61 965 11 01
www.straumann.com

